



3 phase connections - for single phase operation, (if the boiler is 12kW or less) bridge L1, L2, L3 together so that they all connect to single 'live'.

'HDO' (ripple) connected to neutral simulates effect of economy tariff switch in meter - boiler heaters may operate.

'PR1' connected to 'PR2' simulates room programmer switch

Simple connections for Ray boiler when used for central heating only